


## HCN65P 65mm COIL NAILER

For replacement parts contact your usual Tacwise supplier.

### Exploded view drawing



Item	Description	Item	Description	Item	Description
1	Screw	39	Safety Guide	77	Hand Wheel Assembly
2	Bushing	40	Spring Pin 3 x 28	78	Spring
3	Exhaust Cover	41	Spring	79	Washer O-Ring 6.4 x 1.8
4	Seal	42	Bracket	80	O-Ring 12.3 x 1.9
5	Muffler	43	Adjusting Stem	81	Piston
6	Screw	44	O-Ring 6.4 x 1.5	82	Feed Hook Pin
7	Spring Washer	45	Hand Wheel	83	O-Ring 24.3 x 2.8
8	Cylinder Cap	46	Adjusting Seat	84	Spring
9	Gasket	47	Screw	85	Piston Bumper
10	Spring	48	Washer	86	Cover
11	O-Ring 42.8 x 2.65	49	Spring Pin 2.5 x 20	87	Locking Washer
12	Valve	50	Stopped Hook Pin	88	Spring
13	O-Ring 58.7 x 3.5	51	Stopped Hook A	89	Feed Hook
14	Valve Seat	52	Spring	90	Screw
15	Collar	53	Stopped Hook B	91	Spacer
16	Cylinder Seal	54	Latch	92	Pin
17	O-Ring 45.3 x 4	55	Washer	93	Lower Nail Housing
18	Piston Assembly	56	Block	94	Adjusting Stem
19	Cylinder	57	Screw	95	Adjuster Bushing
20	O-Ring 52.4 x 2.5	58	O-Ring 20.3 x 2.5	96	Adjuster Plate
21	Restrictive Plate	59	O-Ring 20.3 x 1.5	97	Adjuster Nut
22	O-Ring 81.8 x 2.65	60	Valve Guide	98	Spring Pin 2.5 x 17
23	Bumper	61	O-Ring 9.5 x 1.9	99	Upper Nail Housing
24	Body	62	O-Ring 10.3 x 1.9	100	Soft Grip Sleeve
25	O-Ring 53 x 1.5	63	Trigger Valve Seat	101	O-Ring 48.8 x 2.5
26	Nut	64	O-Ring 12.8 x 1.9	102	End Cap
27	Washer	65	Spring	103	Air Plug
28	O-Ring 7.5 x 1.5	66	O-Ring 5.5 x 1.5		
29	Protector	67	Trigger Valve Stem		
30	Screw	68	Spring Pin 3 x 26		
31	Spring Washer	69	Trigger Valve Guide		
32	Restrictive Guide	70	Trigger Spring		
33	Nose	71	Rotating Shaft Bushing		
34	Screw	72	Locking Washer		
35	Washer	73	Trigger Assembly		
36	Pin	74	Steel Ball		
37	Safety Bracket	75	Spring		
38	Safety Sleeve	76	Rotating Shaft Pin		