


EHS50V Air Finish Nailer

taking 15G Hard Steel & 16G Finish Nails

For replacement parts contact your usual Tacwise supplier.

Exploded view drawing



Item Description

- 1 Screw
- 2 Washer Spring
- 3 Bushing
- 4 Exhaust Cover
- 5 Seal
- 6 Screw
- 7 Spring Washer
- 8 Cylinder Cap
- 9 Gasket
- 10 O-Ring 36.3 x 2.5
- 11 O-Ring 54.3 x 3
- 12 Spring
- 13 Valve
- 14 Cylinder Seal
- 15 O-Ring 40.2 x 2.3
- 16 Valve Seat
- 17 Stopped Washer
- 18 Washer
- 19 O-Ring 43.3 x 3.5
- 20 Piston Assembly
- 21 Cylinder
- 22 O-Ring 50.5 x 2.5
- 23 Cylinder Sleeve
- 24 Bumper
- 25 Body
- 26 O-Ring 46 x 1.3
- 27 Base
- 28 Screw
- 29 Safe Bracket
- 30 Safe Sleeve
- 31 Spring Pin
- 32 Safe Guide
- 33 Spring
- 34 Safe Bracket
- 35 Trigger Valve Guide
- 36 O-Ring 12.8 x 1.9
- 37 O-Ring 14.3 x 1.9
- 38 Spring
- 39 O-Ring 6.4 x 1.5

Item Description

- 40 Trigger Valve Stem
- 41 Trigger Valve Guide
- 42 O-Ring 12.3 x 1.9
- 43 Trigger Spring
- 44 Spring Pin
- 45 Washer
- 46 Trigger
- 47 Pin
- 48 Support
- 49 Screw
- 50 Spring Washer
- 51 Block
- 52 Drive Guide
- 53 Screw
- 54 Plate
- 55 Latch Sleeve
- 56 Spring Pin
- 57 Latch Assembly
- 58 Front Plate
- 59 Spring Pin
- 60 Spring Pin
- 61 Rail
- 62 Spring Pin
- 63 Movable Magazine
- 64 Screw
- 65 Stopped Plate
- 66 Shoe Feeder
- 67 Spring
- 68 Fixed Magazine
- 69 Screw
- 70 Pin
- 71 Locking Washer
- 72 Torsion Spring
- 73 Lock
- 74 Nut
- 75 Soft Grip Sleeve
- 76 O-Ring 48.5 x 2.5
- 77 End Cap
- 78 Air Plug